



Smart Wireless Earbuds
User Manual
 Model #: P4001

Take your tunes to the streets with a sweat-proof, versatile, low impact, universal Bluetooth in-ear design, that is so small and comfortable, you almost forget you're wearing them.

Easy and smart operation with our one touch multi-functionalities that lets you switch between taking calls and enjoying music to your smart phone.

Contents

- 1x Smart Wireless Earbuds
- 1x USB Cable
- 1x Instruction Manual
- Eartips (S, M, L)

Features

- Dimensions: 31 x 0.9 x 0.39 inches
- Weight: 0.04 lbs.
- Talking time: 4 hrs
- Music playing time: 3 hrs
- Standby time: 40 hrs
- Charging time: 65 mins

Main Features

- Sweat-proof with inner earloops for comfortable wear
- Lightweight design only 0.04 lbs. (18 grams)
- Bluetooth® version 4.0
- Mic and Smart Multi-Function Button for hands-free call, Siri and Google now access
- Rechargeable battery
- iOS & Android compatible

Bluetooth® Pairing

Press and hold the power button until you hear the start-up chime. The red and blue LED lights will be alternately flashing quickly white searching for a pairing compatible Bluetooth device.

Switch on your Bluetooth® device and wait until "PRED Smart Wireless Earbuds" shows up on your screen. When "PRED Smart Wireless Earbuds" appears on your device, select and pair.

When the pairing is complete, you will hear a message and the blue LED light will flash slowly.

Easy operation

- Press once on the multi-function button to Answer/ Hang up Calls/Play/Pause
- Press twice on the multi-function button to Re-dial
- Press and hold the multi-function button for 2 seconds to access Siri, Google Now
- Press and hold for 4 seconds multi-function button: Power on/off

LED Indicator light

- Red and blue LED lights alternately flashing, shows that the headset is Bluetooth® searching and in pairing mode.
- Slow flashing blue LED light indicates that the phone was successfully paired.
- Steady red LED light while the device is charging.

Volume +/- and Forward /Back (During music mode)

- V+: Press and hold to up the volume, one press to forward;
- V-: Press and hold to down the volume, one press to backward;

Check the battery level

If you are on a call or listening to audio you will hear a tone when the battery is low.

Charging

- Fully charge the Smart Wireless Earbuds prior to first use.
- Plug the Micro USB cable into the USB port.
- The red LED light will turn on to indicate the device is charging.
- The red LED light switching off indicates that charging is complete.

Troubleshooting

No Sound:

- Make sure that the music player is working and that the Smart Wireless Earbuds are charged.
- Make sure Bluetooth® is paired with the correct speaker.

Not Charging:

- Check to make sure that you are using the correct cable and that it is fully plugged into both the device and the USB port that you are charging from. Also check to make sure the source is turned on.

Precautions

- Do not submerge the product in water.
- Keep device away from any heat source.
- Adjust volume to avoid damaging your hearing.
- Store and use in normal environments. Exposure to extreme elements such as fire, water, or other extreme elements may damage the unit. Do not handle with wet hands.
- Do not attempt to open or take apart this device. The device will be damaged during that process.
- If the devices's audio quality deteriorates, or a slight 'popping noise' is heard, it may be due to a low battery. Please recharge the device.
- Only use a computer USB or the DC 5V power matching the Micro USB Cable (included) to charge.
- Do not attempt to open or take apart this device. This unit has no user serviceable parts.
- Do not put any foreign objects in the USB port.
- Charge the battery in an isolated area and keep away from flammable material.
- Do not expose product to direct sunlight as it may result in a risk of battery exploding, overheating, or igniting.

- Do not disassemble, modify, short circuit or heat the battery.
- Do not place it in fire or leave in a hot place.
- Only charge the battery with the specified USB cable.
- In the unlikely event of leakage or explosion, use sand or a chemical fire extinguisher to extinguish.
- LiPo Battery must be recycled or disposed of properly.
- The Micro USB cable is tailor-made for the LiPo rechargeable battery used in your Smart Wireless Earbuds. Do not use it to charge any item other than the Smart Wireless Earbuds.

Note

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of

the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or experienced radio/TV technician for help

USA Regulations

This Device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Canada Regulations

This device complies with Industry Canada Licence-exempt RSS-210. Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Manufactured and distributed by Pred Technologies USA Inc.

Product names, designations, and logos are trademarks or registered trademarks of Pred Technologies USA Inc. All rights reserved.

Customer Service Website:
www.predtechnologies.com

We recommend that you retain our address for future reference. Product and colors may vary. Packaging created in San Diego printed in China.

MADE IN CHINA.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For these purposes, the party responsible is:

Pred Technologies USA Inc.
7855 Prospect Street
Suite 310
La Jolla, CA 92037
1-858-999-2114

WARNING! This equipment may experience difficulty and/or memory loss when subjected to any electrostatic discharge, radio frequency interference, or sudden power surge/interruption. The user is encouraged to reset the equipment should any of these occur.

Manufactured and distributed by:
 Pred Technologies USA Inc.
 All Rights Reserved.
 Assortment No:P4001
 Smart Wireless Earbuds



P4001US03CBF