


Quick set up guide:



TOKK™ CAM



1. Confirmation
2. Micro-SD Slot
3. Reset
4. USB Port
5. Mic
6. Lens
7. Indicator

First time set up:

- 1-Download the application called "iCookyCam" on your smart device (APP available on the App Store for iOS and Google play for Android, please make sure not to download the older version of our app called Cookycam but iCookyCam).
- 2- Turn on the camera
- 3- open the app
- 3- add the camera (+)
- 3- select "not been connected to the router"
- 6- go to WIFI settings on your phone
- 7- select iCooky_XXXXXX (if a password is required type 12345678), wait for iCooky to connect.
- 8- go back to the app, press next.
- 9- add device password ok123456 and change the name Camera to the name you want your camera to be called (if you have multiple one this might be handy, to name Entrance, lobby, room 1...) then click on the V on the upper right corner of the app.
- 10- a message "connect to router" appear :
-if you want to connect your camera to your wifi to keep it at home press "yes" then select the name of your Home Wifi router and type your password.
- 11-When you see the message camera succesfully added, just select the camera and press on the play button.

Using TOKK Cam:

Power ON: Press and hold the Confirmation button (1) for about 3 seconds, Red indicator comes on and then Blue indicator flashes slowly
Power Off: Press and hold the Confirmation button (1) for about 5 seconds, Red & Blue indicator flashes for 7 times and turns off

Open your iCookyCam APP, select your camera and press play.

use the speaker icon to turn on the listen function, take picture (Snapshot), record (Video), change Light settingd (for night vision), change the angle (Flip).

In the setting menu you can turn on Motion sensor (this will trigger alert message and start filming), change password, reset...

Tips:

Using the Camera outside your home: Turn on the camera, go to iCookyCam app select the camera, if it says offline check that iCookyCam is selected in your wifi settings, if it is not just select it.

To Add the camera device manually: Click Add a device à Add manually Enter Camera ID which can be found on the back of camera and type passowrd "ok123456".

PRED Technologies USA Inc.
7855 Fay Avenue
La Jolla, CA 92037

1-858-999-2114
contact@predtechnologies.com
www.predtechnologies.com

PRED
TECHNOLOGIES