

Quick set up guide:

TOKK™ SAFE PL15

PRED
TECHNOLOGIES™

Thank you for your order. We hope you will
Enjoy your new TOKK SAFE KB15.

Below is our quick set up guide.
If you want more details please refer
to the complete instruction manual.
If you encounter any issues setting
up your new Safe do not hesitate
to call us and we will be very happy to help you.
Our customer service phone number is
+1 858 999 2114 ext 1.



Step-by-step guide

1. To start: Use the black key ① to open the safe. Once the safe is open, locate the battery holder ② (Inside Safe) Insert 4 AA batteries into the battery holder ②.

2. You are now ready to set up a 6-digit PIN code!

Long press the Setting/Reset Button ③ located on the inside of the safe to the left of the battery holder ②.

After the voice prompt "Please setup Six digit password", insert your desired 6-digit PIN code ④.

Once you have inserted your desired 6-digit PIN code, a voice prompt "please repeat input Six-digit password" will play.

Re-insert the same 6-digit PIN code ④.

You have successfully set up your 6-digit pin code if you hear a last voice prompt "Successful setting"

*If voice prompt "Unsuccessful setting" plays, please restart from step 3.1 and try again.

A new password can be set at any time by repeating these steps.

To ensure you have setup your 6-digit PIN code successfully, close your safe and attempt to open it using your 6-digit PIN code.

3. You are now ready to set up a fingerprint! While the safe is open, place your fingerprint on the

biometric fingerprint reader ⑤. Voice prompt "please setup fingerprint" will play. Short press the digit button "1" ④, then long-press the Setting/Reset button ③. Voice prompt "please setup fingerprint" will play.

Place fingerprint on biometric fingerprint reader ⑤ until a voice prompt "please input fingerprint again".

Release your fingerprint and repeat the process until the voice prompt "successful setting" plays.

*if voice prompt "unsuccessful setting" plays, restart from step 3

To ensure you have setup successfully, close your safe and attempt to open it using your fingerprint scan.

4. In order to add a new fingerprint, open the safe and short press the digit button "1" ④

and long press the Setting/Reset button ③. Repeat step 3.

5. In order to delete all fingerprints from your safe, ensure your safe is open.

Once open, long press Setting/Reset button ③ for 5 seconds. A voice prompt "please setup 6-digit PIN code

"Follow steps 2. To insure the fingerprints have been deleted, close the safe and tap the biometric fingerprint scanner.

PRED Technologies USA Inc.
7855 Fay Avenue
La Jolla, CA 92037

1-858-999-2114
contact@predtechnologies.com
www.predtechnologies.com

PRED
TECHNOLOGIES™