


## Quick set up guide:

# TOKK™ 4K DASH CAM



1. Power Button
2. Micro-SD Slot
3. Reset
4. USB Port
5. Mic
6. Lens
7. Record
8. Switch Video/Photo
9. Cap
10. Wifi

To access the sd card slot / USB / Wifi unscrew the cap (9) at the bottom of the camera)  
If you have a SD card, insert it in the Micro-SD Slot (2).

1- Download the application called “Roadcam” on your smart device (App available on the App Store for iOS and Google play for Android).

2- Power on the Camera (1)

4- Turn on the Wifi from the camera (10)

4- Go to WIFI settings on your smart device.

4- Wait until the wifi named “ActionCam-xxx”, when it appears select it.

-Wait for ActionCamxxx to connect (disregard messages like “unsecured network, or”/no internet access...”) as long as “ActionCam xxx”, is selected as your wifi network you can close the settings.

5- Open the “Roadcam” app, and Press ActionCam xxx, this will open the live view.

6-Configure all the camera parameters directly from the App (open the setting menue upper right corner)

7- Once configured, you can used your action Cam with or without the App (just turn on the cam and press record 7)

Congrats you have set up your new TOKK™ 4K DashCam.

Need more help to set up and check out all the Fonctions of the camera and the App:

Watch our video and download the full app documents on our website: [www.tokktech.com](http://www.tokktech.com)

or call us and we will be very happy to help you. Our phone number is +1 858 999 2114 ext 1