

We hope you will enjoy your new TOKK CAM.

If you encounter any issues setting it up and/or using your new Camera, please do not hesitate to call us and we will be very happy to help you. You can also watch our step by step demo video on our website: www.tokktech.com

Our customer service email is contact@predtechnologies.com Our customer service phone number is +1 858 999 2114

3- Turn on the camera

© 2019 PRED Technologies USA Inc. All Rights Reserved.





1- Download the application called "iCookyCam" on Google play for Android)

2- If you have a SD card, insert it in the Micro-SD Slot.


--> in motion detection mode you will receive a notification router and type your password. and the footage will be recorded on the SD card, if you do not have an SD card you will receive a notification and will have 12- When you see the message "camera succesfully added", to open app and record manually, the footage or picture will and a black screen with the camera status "online" you have be stored on your smart device.

4- open the app "iCookyCam"

your smart device (APP available on the App Store for iOS and might have to type the password a couple of times

Camera to the name you want your camera to be called (if you have multiple ones this might come in handy, to name Entrance, Lobby, Room 1...) then click on the check mark "V"

successfully set-up with your TOKK Cam. Turn off the camera and turn it on again to finalise the set up. It should say online. select the image and touch the play con, the live feed of the camera will appear. If the camera says offline, refer to




8- wait until your camera name appears "iCooky\_XXXXXX", it might take 2 to 3 minutes for the camera to set itself, so wait and refresh your wifi until the camera appears as a choice, when it appears select it, (it should ask you for the password, type "12345678" and join), wait for iCooky... to connect, you

9- go back to the app "iCookyCam", press "next"

on the upper right corner of the app.

11- a message "connect to router" appear:

troubleshooting in the next two page.



10- add device password "ok123456" and change the name B. Screen after selecting the camera

-if you want to connect your camera to your wifi to keep it at home press "yes" then select the name of your Home Wifi

## A. 1st Screen of iCookyCam app



fter selecting the camera.

Power ON: Press and hold the confirmation button for Power Off: Press and hold the confirmation button for 5 seconds and release, the camera will turn off after a few

Using TOKK Cam:

Open your iCookyCam APP, select your camera and press play. Use the speaker icon to turn on the listen function, the camera icon to take picture, the video camera icon to record, change Light setting (for night vision), and change the angel (Flip the camera). In the setting menu you can turn on the Motion sensor (this will trigger an alert message and start filming), change password, reset to factory setting and much more...

Using the camera outside your home: Turn on the camera, go to iCookyCam app select the camera. If it says offline check that iCookyCam is selected in your Wifi settings. If it is not just select it and return in your app.

**Trouble shooting:** To Add the camera device manually: Click

If you have a Micro SD Card proceed to 2.1, if you the "+" to add a device, select "been connected to the router". Press on the pencil icon (bottom right), type in the UID of the camera you want to add (you can find the UID 2.1 Insert Micro SD Card: Class10 or above is recommended. behind the camera. Type in the password "ok123456" and change the name of the camera if you wish to, click on the check mark (upper right corner).

# Complete Instruction Manual




wnload APP download and installation APP from application market.

Android

2.Power ON / Power OFF Operation

do not have a Micro SD Card proceed to 2.2. 3. Connect the Camera to the App Maximum support 64GB, Please format memory card before using.





### 2.2 Power ON: Connect the camera to power supply or long pressconfirmation button for 3 seconds, Red & Blue indicator keeps on and then alternate scintillation, camera starts to initialize(it takes around 60 seconds). After initialization succeed Blue indicator flashes slow camera enters AP connection mode and starts recording automatically. Press confirmation button once to stop video recording, blue indicator keeps on and the camera turns to standby mode.

If the memory card is not inserted, the red and blue indicator flicker at the same time when the machine is initialized, and the camera can't turn on the video. Memory card does not support hot swap, if you want t pull off or insert the memory card, Please turn off the camera first.

2.4 Power OFF: long press confirmation button for 5 seconds, Red & Blue indicator flashes for 7 times and turn off.



< WLAN WLAN ICooky\_K98WHY

🥱 📶 China Mobile 4G 🛑 88%

P 3.1 Choose iCooky\_\*\*\*\*\*

Log into iCookyCam APP, click the "+" in the middle below the interface, then choose "Not been connected to the router", click "Next" to enter the add device interface, input "ok123456" in the device password bar and then click "A". APP will prompt "Connect to the router?", please select "Yes" to enter the "Wi-Fi Network" etup interface. Choose the network you want to connect

and input the right Wi-Fi password, then click "Connect" (P 3.2.1-3.2.7)

P 3.2.1 Login iCookyCam



Cooky 0K94516 P 3.2.6 Click "Yes" P 3.2.7 Connect WiFi P 3.2.5 Input the default password

P 3.3.1 Device list P 3.3.2 Viewing interface 4. If you do not want to connect the Camera to your Home or Office WIFI: 4.1 If you need only AP connections but not IP connections, please select "No" when prompted "Connect to the automatically returns to the device list interface and successfully adds the camera to the list. Click the camera in the list to preview image and control the

camera.(P 4.1.1-4.1.3)

3.3 The camera starts to restart after click "Connect", Please wait for about 90 seconds, at the same time, APP automatically returns to the device list interface and successfully adds the camera to the list. Red indicator flashes slowly after the camera reboots, and the camera turns into IP connection mode. click the camera in the list to preview image and control the camera. (P 3.3.1-3.3.2) . . . . . . . . P 4.1.1 Click "No" P 4.1.2 Device list P 4.1.3 Viewing interface To switch from IP connection mode to AP connection

Ndd the camera manually If the camera has been connected to the Internet to work in IP remote mode, when you want to add the camera to other people's APP please open APP on the other's phone, click the "+" in the middle or below the interface, select the "Been connected to the router"and enter to the" Lan

The state of the s There is no discover. Not been connected to the router Been connected to the router

P 5.2 Click "Been
P 5.1 Click "+" P 5.3 Lan Search interface

5.1 Search addition under the same WiFi same WiFi, then in the "Lan Search" interface will auto matically search all the camera serial numbers under the WiFi, select the camera that you need to add, and input device password (the default password is ok 12345) m+ 100 3TD6FGWSXCKNV5NM111A


Device Name: Camera P 5.1.1 Select a camera P 5.1.2 Input the device password 5.2 Adding your camera to an other Smart Phone: Open the APP that has already added the camera, find the camera that needs to be added in the device list, and click the share button in the lower right corner to automatically generate a camera QR code. Open the

APP on the phone that needs to add the camera, enter the "Lan Search" interface, click the QR code scan button generated camera QR code, and then input the correct device password to add.(P 5.2.1-5.2.5) Ø d One their Ø OFTS

P 5.2.1 Click QR code button P 5.2.2 Generating QR code

Device name — P 5.2.3 Click scan button P 5.2.4 Scan window P 5.2.5 Input the device password "Lan Search" interface to select the manual add button in the lower right corner, and input the correct device

Check video and
Photo taken by APP———Photo + ——Add a device UID and password in the "Add Device" interface to be



6.3 Setting interface Change password——Change Password Device indicator on/off— Indicator Device Information TF card wifi Setting information Tr card information ion—TF Card Information Restore
Restore Sections setting ——factory setting Delete Device

7.Reset Device Password

minute, Please wait patiently.

indicators flash quickly . The machine will reboot

AP Connection Mode Blue Indicator

IP Connection Mode Red Indicator

please do not hesitate to call us and we will be very happy to help you. You can also watch our step by step demo video on our website: www.tokktech.com Our customer service email is contact@predtechnologies.com Our customer service phone number is +1 858 999 2114 ext 1 ----Wi-Fi setting Pred Limited Warranty

Pred Technologies USA Inc. warrants this product against defects in material

Pred Technologies USA Inc Customer Service

Thank you for your purchase. We hope you will enjoy your new TOKK CAM.


If you encounter any issues setting it up and/or using your new Camera,

 Labor and Parts: For a period of 90 days from the date of purchase, if this product is determined to be defective, Pred Technologies will repai or replace the product, at its option, at no charge. 2. Proof of purchase in the form of a bill of sales or receipted invoice which evidence that the unit is within the Warranty period must presented to obtain warranty service.

3. To obtain warranty service, please contact our customer support center: Via email contact@tokktech.com or call 1 858 999 2114 ext 1

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

7855 Fav Avenue, La Jolla, CA 92037



Pred Technologies USA Inc.

© 2019 PRED Technologies USA Inc. All Rights Reserved. Features, specifications and appearance are subject to change without notice.

Manufactured & Distributed by: PRED Technologies USA Incorporated,